

AQA

GCSE

Design and
Technology **8552**

4

Smart materials

Unit 2
Energy, materials,
systems and devices



PG ONLINE

Objectives

- Be able to recognise a range of smart materials
- Understand how the functional properties of a range of smart materials can be changed by external stimuli

Starter

- Smart materials react to an external stimulus by changing their characteristics and/or properties
 - What stimulus is changing the colour of the mug?
 - Why does the handle stay black?



Smart materials

- What different stimuli can make changes occur in smart materials?



Self-healing polymer

- Self-healing polymers react to stress fractures by releasing a resin into the new crack
 - Microcapsules of liquid resin are ruptured to bond the polymer back together again
 - What triggers the resin to cure?



Microcapsules ruptured by fracture



Polymer resin is released into fracture



Resin hardens and heals damage



Self-healing concrete

- Designed to avoid stress cracks filling with water
 - Cracks enlarge over time and water can cause the steel reinforcements to rust and weaken the structure
 - Self-healing concrete has spheres of bacteria added to the mixture which contain their own food
 - When a crack forms and water seeps in, the bacteria start to feed, producing calcium carbonate which fills the crack





Thermochromic pigments

- Hot and cold temperatures trigger a change of colour in special thermochromic dyes
- Applications include:
 - Fever scan strips used on infants
 - Room thermometers
 - Children's cutlery and crockery
 - Novelty goods and colour changing clothing
- Some pigments have a permanent change
 - How might these be useful in the medical or food industry?



Photochromic particles

- Ultraviolet light reacts with photosensitive silver halide particles within the lenses
 - This reaction is commonly seen in prescription sunglasses lenses that darken in bright sunlight and return to clear indoors
 - The reaction can take up to two minutes to complete
 - Over time the particles can lose their ability to revert to clear



UV Light levels



Photochromic pigments

- UV light stimulates particles in a special pigment
- The effect only lasts as long as strong UV light is present
- These pigments are mainly used for novelty goods and colour changing paints
 - How might these pigments be used in improving security?




Shape memory alloy (SMA)

- Nitinol is an SMA of nickel and titanium
 - Nitinol needs to be 'set' into a shape which requires a high temperature of around 540°C
 - Once set, the alloy can be deformed into a different shape
 - Heat or electricity is used to trigger a response in its shape
 - When reheated to around 70°C it will go back to its pre-set shape
- How might nitinol be used in dentistry, eyewear or heart surgery?



Quantum Tunnelling Composite

- QTC is a polymer that contains billions of metal particles that don't actually touch each other
 - It is an unusual material being both an insulator and a semi-conductor
 - When pressure is applied the polymer becomes a conductor allowing an electrical signal to flow
 - Where might this material be useful?



Piezoelectric material

- Piezoelectric material works in two ways:
 - Subject it to movement or stress and it produces electricity
 - Attach an electrical signal to it and it moves
- How might it be used to detect vibrations?



Piezo transducer

- Using a thin layer of piezoelectric material, small transducers vibrate when an electrical signal is sent through the contacts
 - These are used in mobile phones and other small electronic devices and toys
 - When tapped or spoken into they produce a small electrical charge that can be amplified to create sound or trigger a response in a circuit



Acid or alkali?

- PH levels can be detected using litmus paper
 - It uses compounds found in different varieties of lichen
 - Different colours and shades appear depending on the PH
 - Common uses include: Garden soil testing / pool water testing / skincare products – (dermatological testing)



Worksheet 4

- Complete **Tasks 1** and **2** of the worksheet



Plenary

- Imagine you are a designer for a car manufacturer
 - You have been asked to create the best driving experience for their customers
- How could smart materials be used to help you design the ultimate car?
 - Consider all aspects of the passenger experience including safety, entertainment, comfort, easy of use of controls, reduced maintenance etc.



Copyright

© 2017 PG Online Limited

The contents of this unit are protected by copyright.

This unit and all the worksheets, PowerPoint presentations, teaching guides and other associated files distributed with it are supplied to you by PG Online Limited under licence and may be used and copied by you only in accordance with the terms of the licence. Except as expressly permitted by the licence, no part of the materials distributed with this unit may be used, reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic or otherwise, without the prior written permission of PG Online Limited.

Licence agreement

This is a legal agreement between you, the end user, and PG Online Limited. This unit and all the worksheets, PowerPoint presentations, teaching guides and other associated files distributed with it is licensed, not sold, to you by PG Online Limited for use under the terms of the licence.

The materials distributed with this unit may be freely copied and used by members of a single institution on a single site only. You are not permitted to share in any way any of the materials or part of the materials with any third party, including users on another site or individuals who are members of a separate institution. You acknowledge that the materials must remain with you, the licencing institution, and no part of the materials may be transferred to another institution. You also agree not to procure, authorise, encourage, facilitate or enable any third party to reproduce these materials in whole or in part without the prior permission of PG Online Limited.